AUUMP100SL



Use (*)









Technical features

- Designation: Filtering face-piece respirator.
- Filters solid and liquid aerosols. Horizontal fold-flat. Single-use. Latex-free continuous loop. Adjustable nose piece to minimise leakage but maximise comfort.
- Material: non-woven polypropylene.
- Color: white. (yellow nosepiece).
- Classification: FFP1 NR D.
- Expiry date: if maintained as per storage instructions, product can be used up to 5 years from date of manufacture.
- Packing: carton of 12 boxes.
 - boxes of 20 units.
 - each mask under individual polybag.

Learn more: www.singer.fr



Advantages

- Foldable design and easy carry/storage. Individually hygienically packed.
- Sealed edge avoids fluffy open layers and eliminates the possibility of irritation.
- ✓ P.P. outer/inner layers provide smooth lining and comfortable feel.
- Soft edges can fit different facial shapes with minimum leakage.
- Latex-free continuous loop design can allow to hang the mask around the neck when not in use.
- Light wear and comfortable. Easy breathing/Speaking. Clear vision. Free maintenance (disposable item).
- Pass the « D » dolomite clogging test.
- The ISO 9001 / ISO 14001 certified production guarantees the reliability / regularity of the production and the control of the environmental impact.

Certification

This product complies with European Regulation (EU) 2016/425 on Personal Protective

Equipment (PPE). Category III.

Issued by BSI (The Netherlands).

Notified body n°2797.

EN 149 : 2001 + A1: 2009

EN149: requirements	FFP1	FFP2	FFP3
Total inward leakage	< 22%	< 8%	< 2%
Maximum penetration of test aerosol (Sodium chloride or paraffin oil)	< 20%	< 6%	< 1%
Breathing resistance			
- inhalation (30 l/min)	< 0,6 mbar	<0,7 mbar	< 1,0 mbar
- inhalation (95 l/min)	< 2,1 mbar	< 2,4 mbar	< 3,0 mbar
- exhalation (160 l/min)	< 3,0 mbar	< 3,0 mbar	< 3,0 mbar



Download the EU declaration of conformity on http://docs.singer.fr

(*) Type of use is given as a guide only. It is to the end user to check whether the product is suitable or not for the intended use. Before any use, read carefully the instructions enclosed with the product. Issue LS_2021_04_22 / Copyright Singer® Safety

